







## Use

 For measurement of inner diameter or dimension of gap

## ■Formula for revision

Use the formula below to correct for error when measuring inner diameter

(B)

(A)

(C)

(B) = 
$$\sqrt{(A)^2 + (C)^2}$$

- (A) Reading value
- (B) Inner diameter
- (C) Thickness of Taper Gauge (1.2 mm/0.047 in)

## **⚠ WARNING**

●This product can expose you to Nickel, which is known to the State of California to cause cancer. For more information go to www.P65Warnings.ca.gov.

## **⚠** CAUTION

- Do not use other than as intended
- Error occurs with the thickness of the gauge itself when measuring inner diameter.
  - Please correct as directed above.
- Use caution as the tip is sharp and dangerous
- Do not drop or subject to strong impact as this may cause damage or deformation
- Store out of the reach of children

# **■**Specification

Measuring Range	1 - 15 mm 1/16 - 5/8 in
Accuracy	±0.05 mm ±0.002 in
Hardness	Hv400 or more
Material	Stainless steel
Body Size	5-43/64" x 43/64" x 3/64"
Weight	11 g

## Shinwa Rules Co., Ltd.

3481 Koike, Tsubame, Niigata, 959-1276 JAPAN URL https://www.shinwasokutei.co.jp/english/MADE IN JAPAN